# Port Forwarding on Linksys Router

Step 1: Open your web browser and enter the router IP address in the address bar. Enter username (blank by default) and then password ("admin" by default)

Step 2: Click **Applications & Gaming→ Single Port Forwarding** tab.

You enter a name what you like for the port forwarding. (Eg: Camera01)

Enter camera's port number in External Port and Internal Port, select TCP fro Protocol. (Eg: 8090)

Enter camera's IP address and check Enable box. (Eg: 192.168.1.190)

After completing all the necessary entries, go to the bottom and click **Save Settings**.

You can check port is forwarded successful or not from

http://www.yougetsignal.com/tools/open-ports/ .

Step 3: View camera over Internet by external IP address or host name and port number.

(Eg: http://14.153.222.148:8090 or http://tech3.dyndns-remote.com:8090)