

How to upgrade firmware for MJPG camera


Suitable for MJPG camera: FI8903W, FI8904W, FI8905W, FI8907W, FI8908W, FI8909W, FI8910W, FI8916W, FI8918W, FI8919W.

Plug in the Ethernet cable to upgrade firmware, not via wireless. Upgrade the system firmware firstly and web UI secondly. Keep power on during the upgrading. Updating with the wrong firmware may severely damage and/or break your camera. Please make sure the firmware is right and update at your own risk.


Download firmware from <http://www.foscam.com/down3.aspx> and unzip firmware.

Method 1: Upgrade firmware on IP Camera Tool

Step 1: Highlight and right click the camera and then go to **Upgrade Firmware**.





Step 2: Enter the user and password of camera. The default user is 'admin' and password is blank.




Step 3: Update System Firmware.

Click **Upgrade System Firmware** → select system firmware → click **Open**.




Step 4: Upgrade Web UI.

Repeat step 1 and 2. Click **Upgrade Web UI** → select Web UI firmware → click **Open**.

**Step 5:** You can check new firmware on **Basic Properties**.


Highlight and right click the camera and then go to **Basic Properties**.

**Method 2:** Update firmware on **Upgrade Device Firmware**.**Step 1:** Log into camera click **For Administrator** → **Upgrade Device Firmware**.

For Firefox, Google Chrome and Safari, click **Device management** → **Upgrade Device Firmware**.


Step 2: Update System firmware.

Click **Browse** → select system firmware → click **Open** → Click **Submit**.



Step 3: Update WebUI firmware.

Click **Browse** → select system firmware → click **Open** → Click **Submit**.



Step 4: You can check new firmware on **Device Info** page.

Real-time IP Camera Monitoring System

Device Info	Device Status	
Alias Settings	Device ID	000DC5D434DC
Date&Time Settings	Device Firmware Version	11.22.2.38
Users Settings	Device Embedded Web UI Version	2.4.18.17
Multi-Device Settings	Alias	Anonymous
Basic Network Settings	Alarm Status	None
Wireless LAN Settings	DDNS Status	No Action
ADSL Settings	UPnP Status	No Action
UPnP Settings	MSN Status	No Action
DDNS Service Settings		
Mail Service Settings		
MSN Settings		