									A	larm	Serv	ice S	ettin	g										-	
Motion Detect Armed Enables Motion Detect													tion												
Motion Detect Sensibility							5	V	The s	mall	er the	valu	e, the	e mor	e sei	nsitiv	ity		7	Sets	s se	nsit	ivity	level	
Audio Ala	arm S	ensit	ivity				Dis	able	į		~				E	Enab	oles	Au	dio	Det	ecti	on a	nd	sets s	ens
Alarm In	put Ar	med				Ī							U	sed	for	I/C	pa:	nels	on	bac	k				
Trigger L	.evel						Lov	, V	]					Į	Jse	d fo	or I/e	Ор	ane	ls o	n ba	ack			Н
										Alan	n trig	ger e	vent					- 10.							Н
Alarm preset linkage															Н										
IO Linka	ge on	Aları	n													τ	Jsed	for	r I/C	) pa	mel	s or	ı ba	ck	Н
Output Level  Send Alarm Notification by Mail							Low V Used for I/O panels on back														Н				
Send Alarm Notification by Mail							☐ Enable sending email after an alarm is triggered																Н		
Upload Image on Alarm							☐ Uploads image to FTP server when alarm triggered															d	н		
Upload picture count							0 (0~10) Number of images to upload to FT															P se			
Alarm recording							☐ Records video to SD card when alarm triggered																Н		
									9	Alarr	n Arr	ning	Time												Н
Schedule	er						<b>V</b>	7	Whe	n tl	ne c	ame	ra s	shou	ıld	dete	ct s	our	nd a	nd/o	or n	noti	on		Н
Select all							☑ Fill in time grid																Н		
Day	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	Н
Sun																									Н
Mon																									Н
Tue				Sinc	rle c	lic	k to	ado	l/re	mov	re I	5 m	imut	e in	tem	al.									
Wed																									
Thu		Double click to add/remove 1 hour interval																							
Fri																									
Sat																									

Submit

Refresh

